

# Quick Guide

## WebZeal(Web-browsing) & YouTube

Your sample has Web Browser and You Tube features.

To use both features, you need to follow some steps as below.

And about recording, disconnecting and reconnecting points, you can check the sentences in red color.

### [ WebZeal ]

- Download the file from the link below(bottom of this email) and unzip the file.
- Prepare USB memory stick and download “WebZeal-20101119.mnt” file on USB
- To connect “WebZeal-20101119.mnt”, insert USB on Receiver and go to the “Storage Manager” menu  
You need to change “Current Device” from ‘USB1 (Front)’ to ‘File Mount Drive’



Move cursor to “Connect: and press “OK”



You will see the changes for Total value as 38MB and Free value as 5% (2 MB).



Press “EXIT” and then go to the Plugin menu.

You will see “WebZeal (v1.60su)” icon and press ‘Green’ button and make ‘Yes’ to activate Web feature.

You will see “Please wait” message and “Loading... from 0% to 100%” and “Finished Loading..”.

Now you will see web page with Google probably.  
Press Menu on RCU and you can change web address and so on.  
Press “EXIT” button once to escape from WebZeal.

- **To record**, USB memory stick with “WebZeal-20101119.mnt” can be used for recording at the same time, but you cannot use WebZeal during recording.  
If you try, you will have message like this "Will you stop the recording as well?" “Yes, No, Cancel”.  
If you want use WebZeal during live recording, you need to use another USB memory stick or External USB HDD on the other USB port.

- **To disconnect** “WebZeal-20101119.mnt”, go to “Storage Manager”.  
You need to change “Current Device” from ‘USB1 (Front)’ to ‘File Mount Drive’



Move cursor to “Disconnect” and press “OK”.  
You will see the change for Total value is 0 and Free value is 0.  
This stage is necessary for safety removing like between PC and USB stick.

- **To reconnect**, you don’t have to make same “File Mount Drive” process whenever you turn on the receiver, but this condition will be stayed if you don’t make disconnect or take USB stick off from the receiver.  
You can test remove and put again USB stick (with .mnt) and you can use WebZeal.  
But this process (remove and put again) might bring unexpected problem like not supporting recording.  
If you have this problem, you need to make AC Power Switch Off/On.

### **[ You Tube ]**

- You don't need to make mount "WebZeal-20101119.mnt" for one You Tube uses, but just need to put USB stick on receiver.
- Go to "Utilities" and find "You Tube" and press "OK" then you will see some Contents.
- Select anything which you want to watch and press "OK".
- You can find contents by search, Location and Category.
- Press "EXIT" button once to escape from "You Tube".